



STUDIO PEJOT


HELMET SERIES





2




3






6




7






The installation of the lifting mechanism of RF module
VERSION WITH LEGO™ GEARS (all parts included)



The installation of the lifting mechanism of RF module
STANDARD VERSION



10

Darkening T-visor by using dimming film (included)

1

remove the protective film




2

water with a few drops of detergent



3

use hard sponge or rubber to squeeze water



4

cut off on the edge of T-visor



11

Method of bonding T-visor by using epoxy glue (or similar)



The order of gluing T-visor

